inkana

ULTRA CLEAR GLOSS AND MATTE WHITEBOARDS

Care and Maintenance Guide

OVERVIEW

Inkana Gloss and Matte glass whiteboards have a non-porous surface that will not stain or ghost. The same simple care applies to both.

EVERYDAY CLEANING

Erase with a standard eraser or a soft, dry microfiber cloth. Keep erasers and cloths free of grit.

ERASER CARE

The pad on the Inkana beechwood eraser is removable. When it gets dirty, remove the pad, wash it, and let it dry fully before reuse.

DEEPER CLEANING

Spray glass cleaner onto a clean, lint-free cloth rather than directly onto the board. Wipe the surface, then dry it with a second cloth to avoid streaks.

For permanent marker, tape residue or stubborn ink, use isopropyl alcohol on a cloth, then wipe dry.

MARKERS

Use dry-erase markers. Solvent-based dry-erase markers give the best writing experience and contrast.

AVOID

Scrapers, razor blades, abrasive pads and abrasive cleaners.

Cleaners that leave wax or detergent residue, including furniture and laminate cleaners.

Leaving tape or adhesives on the glass for long periods.

No abrasives

NEVER USE SCRAPERS, RAZOR BLADES, ABRASIVE PADS OR ABRASIVE CLEANERS

Eraser or microfiber

EVERYDAY ERASING. ERASER PAD IS WASHABLE

Glass cleaner

ON A CLOTH, WIPED DRY

Isopropyl alcohol

PERMANENT MARKER AND RESIDUE

INKANA CONTACTS

SALES 833-247-8343
sales@inkanafurniture.com

©2026 Inkana Inc.